

PARTS LIST FOR MODELS FRG AND FRG-CPG 09/07/10

	DRVES	P/N
1	Drive Head - SQ Base w/ Sleeve Arbor	use description
2	Drive Head - SQ Base w/ Flange Arbor	use description
3	Drive Head/Stool w/ Sleeve Arbor	use description
4	Drive Head/Stool w/ Flange Arbor	use description
	EXTERNAL PARTS / CASTINGS	
5	Angle Risers - (Pair L&R)	316314 L&R
6	Flex Bolt Mounts	322646P1-5
7	Tall Stool Bearing Housing	315617
8	Square Base Bearing Housing	315607
9	Gear Case	311084
	REBUILD & MAINTENANCE PARTS	
*	10 Gear	310151
*	11 Pinion	313828
**	12 Gasket (2)	314459
*	13 Gear Key	310268
*	14 Drive Pin	320958P1
**	15 Retaining Ring	330449
**	16 Locknut	315385
**	17 Lockwasher	329387P01
**	18 Lower Bearing	322852P1
**	19 Upper Bearing	320840P1
**	20 Oil Seal	330289
**	21 Hardware Kit	HKIT1
	22 Rebuild Kit (* included in kit)	KIT2
	23 Maintenance Kit (** included in kit)	KIT4
	ARBORS	
24	Sleeve Arbor (Steel)- 3/4"	315618-6
24	Sleeve Arbor (Steel)- 1"	315618-4
24	Sleeve Arbor (Steel)- 1-1/4"	315618-5
24	Flange Arbor (Steel)	315625
24	Sleeve Arbor (316SS)- 3/4"	315618-6S
24	Sleeve Arbor (316SS)- 1"	315618-10
24	Sleeve Arbor (316SS)- 1-1/4"	315618-12
	STUFFING BOX / FLANGE PARTS	
25	Flange 50# w/ High Pressure Stuffing Box-(7 pc. Incl.)	use serial number
26	Flange 50# w/ Low Pressure Stuffing Box-(2 pc. Incl.)	use serial number
27	Packing - 3/8 graphite	901300
28	Lantern Ring - 3/4"	A8456
28	Lantern Ring - 1"	A8457
28	Lantern Ring - 1.25"	A8447
29	Split Follower - 1"	330450
29	Split Follower - 1.25"	330451
29	Split Follower - 1.50"	330452
30	50# Flange	call factory
31	Grease Fitting	320145P1
32	Removable 1/2 Coupling - 1"	330440
32	Removable 1/2 Coupling - 1.25"	330441
32	Removable 1/2 Coupling - 1.50"	330442

CLEVELAND MIXER - www.emimixers.com (860)-669-1199